

LIGHTING & DECORATING PLASTERBOARD GUIDE



TABLE OF CONTENTS

	1
1.0 EXAMPLES OF UNPAVOURABLE LIGHTING	4
2.0 DESIGN INFLUENCES	5
3.0 NATURAL LIGHTING INFLUENCES	6
4.0 GLANCING LIGHT	8
5.0 DIFFERENT LIGHTING CONDITIONS	10
6.0 LIGHTING	12
Favourable & Unfavourable Lighting	14
7.0 GLOSS/SHEEN PAINT FINISHES	16
8.0 PAINTING PREPARATION AND APPLICATION	17
Preparation	17
Application (Level 4 Finish)	17
9.0 LEVELS OF FINISH	18
Definition	18
Level 3	18
Level 4	18
Level 5	18
10.0 JOINT INSPECTION AND TOLERANCES	19
Points to Remeber	19

This Guide is intended for use by Building and Interior Designers, Builders, Contractors and Property Owners. It highlights some of the key factors affecting the appearance of flat plasterboard surfaces, and provides guidance on eliminating or reducing the undesirable effects due to unfavourable lighting conditions or inappropriate decoration.

Developed and published by Knauf, this Guide has been endorsed by the following industry organisations:



This Guide contains the following information:

- An overview of various types of light sources both natural and artificial used to illuminate building interiors
- Explanations of the possible problems that may arise when flat plasterboard surfaces are illuminated by various light sources
- Suggestions of what to do and what to avoid in order to mitigate the problems if they arise
- The effect of illumination on decorative finishes such as gloss or sheen paints

For additional information on finishing and decoration of plasterboard refer to the following publications:

- AS/NZS 2589 'Gypsum linings Application and finishing'
- AS/NZS 2311 'Guide to the painting of buildings'
- 'Illumination & Decoration of Flat Surfaces', CSIRO 2009

INTRODUCTION

There is little doubt that most customers have an expectation of a perfectly flat, blemish- free plasterboard surface finish. In practice, however, such finish is impossible to achieve and all that can be realistically expected is the perception of flatness.

Experience shows that satisfaction with plasterboard surfaces improves considerably when the following requirements have been met:

- Accurate installation of wall/ceiling framing and roof trusses
- Use of ceiling battens
- Plasterboard installation to Australian Standard AS/NZS 2589 'Gypsum linings – Application and finishing'
- Good painting practice to Australian Standard AS/NZS 2311 'Guide to the painting of buildings'
- A planned approach to lighting design and installation.

It should be emphasised that even if plasterboard installation has been carried out strictly in accordance with AS/NZS 2589, surface finish expectations may not be met unless the other requirements listed above have also been satisfied.

A major cause of dissatisfaction with plasterboard surfaces is, in fact, unfavourable lighting from internal or external sources.

1.0 EXAMPLES OF UNFAVOURABLE LIGHTING



Large uncurtained windows allow external light reflections (especially from water) to emphasise surface irregularities on adjacent walls and ceilings



Outdoor highly reflective surfaces



Incorrectly positioned spotlights



Energy saving downlights protruding from ceiling



Indiscriminate use of gloss paints



An unshaded batten holder light globe



Ceiling fluorescent lights

2.0 DESIGN INFLUENCES

There are many factors in modern building design that influence the overall appearance of walls and ceilings.

Many of today's homes have large open living areas with unbroken ceilings across adjoining rooms and, importantly, large windows and skylights. While providing the desired modern and spacious look, these features often create lighting conditions detrimental to the appearance of wall and ceiling surfaces.

It is important that surface finish expectations are based on what can be realistically achieved given the design features of the project, particularly when some design features are likely to magnify any minor surface irregularities.

When considering the effects of building orientation and window size and positioning on appearance of wall and ceiling surfaces, one should be aware of the effects of external light at different times of the day.





Compare a modern house with large windows





To the small windows of heritage design homes

3.0 NATURAL LIGHTING INFLUENCES



be worse than direct light in that it strikes the

surface from many angles.

4.0 Glancing light

When architects, builders and home owners are considering what standard of finish is desired for plasterboard walls and ceilings, it is important to understand how the overall appearance is likely to be affected by glancing light.

Glancing light is the light that shines directly across the surface of a wall or ceiling. Glancing light magnifies surface irregularities and can spoil the look of the highest quality surface finish.

A wall or ceiling surface may be subjected to many different lighting conditions. Lighting direction and intensity changes constantly throughout the day and at night, depending on the position of windows and lighting – as well as reflections from adjacent buildings, water surfaces, etc.

As plasterboard linings are constructed on site using materials of two different surface textures and porosity (paper faced plasterboard and jointing compound), they cannot be expected to have a perfect, blemish-free surface. Glancing light creates shadows from even minute undulations, so it will highlight surface irregularities that would not normally be visible under a more diffuse light. Critical instances of glancing light can occur when a single unshaded light source is fixed directly to the ceiling or wall, but also in rooms with windows up to ceiling height or adjacent to walls.

A particularly severe glancing light problem occurs when a surfacemounted fluorescent batten light fitting is placed parallel with the plastering joints. Resultant high intensity white light falling at a shallow angle will magnify any surface irregularities (right).

Incorrectly positioning a spotlight to highlight an object can also create a glancing light effect emphasising surface irregularities onwalls and ceilings. Feature or spot lights should only light the featured object (below).



Frontal light reduces or eliminates shadows to give a perception of perfectly flat surface



Glancing light throws deep shadows emphasising surface irregularities



Plasterboard joint under diffused frontal light



The same plasterboard joint under glancing light



Glancing light can reflect upwards from pool water onto interior walls and ceilings



Correctly positioned spotlights





Glancing light due to large window abutting wall and ceiling



Incorrectly positioned spotlights

5.0 DIFFERENT LIGHTING CONDITIONS



A plasterboard ceiling under glancing light conditions



The same ceiling under different lighting conditions when viewed from another angle



Wall surface under glancing light conditions caused by direct sunlight



The same wall surface under indirect light

A number of measures can help reduce or eliminate the effect of glancing light on interior surfaces:

- Diffuse and soften the light entering the room through windows by using mesh curtains or other diffusers.
- Use a number of lower-wattage light bulbs (rather than one or two bright ones) to illuminate the room, thus reducing the shadowing effect.

- Use suspended or recessed ceiling lights.
- Select shades that direct light downwards or directly at the feature to be highlighted.

6.0 Lighting

Lighting is one of the most important elements in building design and can add that special finishing touch.

One must be aware of the effects of glancing light when considering lighting types and positioning.

Modern lighting solutions can help to balance illumination and shadow and to achieve a better outcome in a new home or commercial project.

Although the selection of light fittings is usually governed by taste and budget, it is wise to consider lighting effect on internal surfaces even before construction is started.

Large living areas, that are a feature of modern open plan designs, are the most severely affected by glancing light. Consideration should be given to illuminating such areas with general diffused light using downlights or spotlights, in combination with local accent lighting such as floor lamps, table lamps, etc.



Recessed ceiling lights close to a wall highlight texture variations on wall surfaces

Cautionary Notes:

• Fluorescent or unshaded ceiling lights installed in kitchen areas that form part of a large open living area will, in some cases, create unfavourable effects on ceilings in the other zones by highlighting variations in the finished surface.

In two-storey dwellings, some downlights may not fit within the floor cavity. This needs to be taken into account at design stage.



6.1 LIGHTING

Favourable Lighting



Unfavourable Lighting

and highlights surface variations



An opaque shade directs the light downwards to illuminate the room not the ceiling



A recessed fluorescent light avoids ceiling shadows and does not highlight surface variations



Unguarded fluorescent lights close to the ceiling highlight surface variations and cast unsightly shadows



Recessed downlights and spotlights avoid glancing light by providing an even downward illumination



Ceiling mounted circular fluorescent lights provide very strong glancing light and accentuate surface variations

Favourable Lighting



In some circumstances, fluorescent lights installed directly over butt joints may help to conceal the joints



An area of ceiling in daylight. No surface variations are visible when ceiling light is off

Unfavourable Lighting



Fluorescent light tubes should not be run parallel to the long edges of plasterboard sheets



The same area at night when lit by ceiling mounted round fluorescent light

7.0 GLOSS/SHEEN PAINT FINISHES

Gloss and even semi-gloss paints will accentuate surface variations regardless of the direction of lighting or the viewing angle. Flat paints however, reflect light in a diffused form and thus mask surface variations.

As plasterboard's paper surface has a different surface texture from hand applied jointing materials, this difference in texture can be accentuated by gloss paints.

Where gloss or impervious sheen paint finishes are desirable or mandatory for functional reasons (eg in kitchens, bathrooms and commercial food preparation areas), some loss of appearance can be expected, even when the work has been carried out to the highest level of workmanship.

For the reasons outlined, a full gloss paint finish is not recommended on plasterboard walls or ceilings.

Where gloss or semi-gloss paints are to be used, the highest level of plasterboard finish as stipulated by AS/NZS 2589 'Gypsum linings – Application and finishing' is recommended (Level 5 finish; see Levels of Finish page 19).

Careful consideration must also be given to:

- The placement of windows
- The type of lighting
- The standard of paint finish
- The positioning of plasterboard joints (both butt and recess)
- Building aspect Northerly? Westerly?



A gloss paint finish subjected to external glancing light



Surface finished with matt paint



Surface finished with gloss paint

8.0 Painting preparation And application

Preparation

The quality of a painted finish can be improved if adequate steps have been taken to prepare plasterboard surfaces prior to painting:

- All surfaces should be clean and dust free prior to painting.
- Any major defects visible after the first (sealer undercoat) coat of paint should be referred to the plasterboard contractor before proceeding with the second and final coats. Minor blemishes are normally wattended to by the painter.

Application (Level 4 Finish)

For the best results, Knauf recommends roller paint application and the use of a suitable sealer undercoat over the entire plasterboard surface in order to equalise porosity and texture of the jointing material and plasterboard paper face.

Sealer undercoat should be lightly sanded before applying the second paint coat.

As spray painting does not impart a textured surface and does not equalise the porosity of what is essentially two different materials, it tends to emphasise the paper nap and accentuate joint locations.

If the spray painting method is to be used, it is recommended that all paint coats are backrolled and allowed to dry thoroughly prior to application of subsequent coats.

Backrolling must be carried out over wet paint to create a textured background for subsequent paint coats.

Choice of colours is also important, as some darker colours tend to highlight surface variations. Light colours give better results, and white is recommended for ceilings (refer to AS/NZS 2311 'Guide to the painting of buildings').

9.0 Levels of finish

Definition

The term 'level of finish' applies to plasterboard linings prior to decoration. AS/NZS 2589 'Gypsum linings – Application and finishing' defines three levels of finish: Levels 3, 4 and 5. Level 4 is the default level of finish for plasterboard surfaces, unless otherwise specified.

It is essential that the level of finish is determined at the design stage since each level of finish has specific requirements for substrate tolerances and plasterboard installation, jointing and finishing. The desired level of finish may not be achieved unless all of these requirements are met through various stages of construction.

For a full description of levels of finish refer to AS/NZS 2589. A summary of various levels of finish is provided below:

Level 3

This level of finish is used in areas that do not require decoration or where finish is not important (for example, above ceilings or inside service shafts and the like). All joints and interior angles must have tape embedded in the joint compound and one separate coat of joint compound applied over all joints and fastener heads.

Level 4

This is the default and generally accepted level of plasterboard finish.

All joints and interior angles must have tape embedded in the jointing compound and a minimum of two separate coats of joint compound applied over all joints, angles fastener heads and accessories.

If Level 4 surface is to be exposed to critical lighting (see Glancing Light above), it should be covered with textured finishes or wall coverings. Smooth textured finishes and flat/matt or low sheen paints can be used when Level 4 finish is illuminated by non-critical lighting. Flat paints in this situation tend to conceal joints.

Weight, texture and sheen level of wall coverings/finishes should be carefully evaluated and joints should be adequately concealed if wall-covering material is lightweight, glossy or lightly patterned.

Notes:

- In critical lighting conditions, surface variations may still be apparent in a Level 4 surface finish.
- Gloss, semi-gloss or deep tone paints are not recommended for Level 4 finish, as they accentuate surface variations.

Level 5

Level 5 finish should be used where gloss or semi-gloss paints are specified or where flat or low sheen paints will be exposed to critical lighting conditions. Level 5 finish is characterised by a parity of surface texture and porosity.

All joints and interior angles must have tape embedded in the jointing compound and a minimum of two separate coats of jointing compound applied over all joints, angles, fastener heads and accessories. The work is finished with proprietary surface preparations or skim coating to remove differential surface textures and porosity. A suitable paint or plaster material is sprayed, rolled or trowelled over the defined area. The surface texture must be random and monolithic, concealing joints and fixing points.

Notes:

- If Level 5 finish is desired for a decorated plasterboard surface, this must be specified at the design stage.
- Level 5 finish does not mean the surface is without texture variation.
- Level 5 finish is difficult to achieve and always requires the cooperation of the framer, plasterer and painter in establishing suitable work practices that deliver the agreed painted finish for the given project.
- Some minor surface variations may still be visible in Level 5 finish. However, these will be minimised.
- The surface of the defined area may require sanding to be suitable for decoration.

10.0 JOINT INSPECTION AND TOLERANCES

Preparation

As outlined in AS/NZS 2589 'Gypsum linings – Application and finishing', a visual inspection of wall and ceiling surfaces should be carried out from a distance of 1.5m or greater, under normal lighting conditions. Plasterboard surfaces should not be inspected under high intensity lighting or under glancing light conditions.

Allowable tolerances for plasterboard joint build-up are outlined in AS/NZS 2589 'Gypsum linings – Application and finishing'.

Refer AS/NZS 2589 and the relevant industry publications for guidance on conducting plasterboard joint inspections.



Points to remember

Plasterboard surfaces are never perfectly flat. Even with the most careful professional finish, every surface will contain variations.

Surface variations invisible under normal lighting conditions will almost certainly be emphasised by a combination of glancing light and sheen or gloss paint finishes. Glancing light can be caused by natural lighting conditions or by certain types of artificial lighting. Unfavourable factors include:

- Large uncurtained windows
- Unshaded light bulbs
- Ceiling-mounted fluorescent lights
- Incorrectly-positioned spotlights
- Gloss or sheen paint finishes
- Outdoor reflective surfaces (eg pools, canals, adjoining steel roofing and painted walls)
- Plasterboard joints parallel to a glancing light source.



KNAUF SERVICES



TECHNICAL ASSISTANCE

TecASSIST[™] - 1800 811 222

Our National TecASSISTTM helpline is available to answer technical questions and provide free advice to builders, contractors, architects, engineers and home owners throughout Australia.

There are many variables that can influence construction projects, which affect whether a particular construction technique is appropriate. Before proceeding with any project, we recommend you obtain professional advice to ascertain the appropriate construction techniques to suit the particular circumstances of your project. We recommend you use qualified tradespersons to install this system.

The technical information contained in this manual was correct at the time of printing. Building systems, details and product availability are, however, subject to change. To ensure the information you are using is current, Knauf recommends you review the latest building information available on the Knauf website.

For further information, contact TecASSIST™ or your nearest Knauf sales office.



WHERE TO BUY

1800 003 377

If you are wondering where to buy plasterboard and other building materials such as cornice, compounds, ceilings and plastering tools, you can be confident that wherever you are located in Australia, you will be able to find a convenient Knauf store or stockist near you using our store finder.



DOCUMENT FINDER

knaufapac.com/au/resources

Find a Knauf product brochure, installation manual, Product Data Sheet or Whitepaper with the new document finder tool.

See **knaufapac.com** for the most up-to-date product information.

© 2018, 2022* Knauf Gypsum Pty Ltd. All rights reserved. KNAUF and TECASSIST are trademarks of Knauf Gypsum Pty Ltd or one or more of its affiliates, including Knauf Gips KG. SHEETROCK and FIBEROCK Aqua-Tough are registered trademarks of United States Gypsum Company and used under license. ABN 84 004 231 976. 3 Thackeray Street, Camellia NSW. To ensure the information you are using is current, KNAUF recommends you review the latest building information available on the KNAUF website knaufapac.com KNA001 02/22

Knauf Gypsum Pty Ltd. 3 Thackeray Street, Camellia NSW 2142 Australia